



Dimensions

A - Seat Depth - 22"/ 56cm B - Seat Height - 21"/ 53cm C - Arm Height - 26"/ 66cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- Seat Fill 1.8 lb high resilience foam for superior comfort without loss of support
- Back Fill Blown fiber back cushions
- Inside Latch for manual operation
- D-pull for manual operation of armless skus
- Toggle Switch for power operation
- LED cupholder switch for power operation
- Touch button for power operation

Options

- Stainless Steel Cupholder
- Antique Cupholder
- LED cupholder with groundlighting
- Tray tables
- · Wireless Bass Shaker

41408 EQUALIZER



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. **LHF** - left hand facing **RHF** - right hand facing **IA** - inside arm to inside arm. For SKU options: **R**=Manual Recline, **E**=Power Recline



1R-Manual Recliner 39 x 42 x 42" 99 x 107 x 107cm

7R-RHF Wedge, Man

102 x 107 x 107cm

IA: 23" / 58cm

Recliner

40 x 42 x 42"



2R-LHF Arm, Man Recliner 31 x 42 x 42" 79 x 107 x 107cm

Recliner



3R-RHF Arm, Man Recliner 31 x 42 x 42" 79 x 107 x 107cm



4R-Armless Loveseat Man Recl 47 x 41 x 42" 119 x 103 x 107cm



5R-LHF Arm, RHF Wedge, Man Recl 48 x 42 x 42" 122 x 107 x 107cm IA: 23" / 58cm



6R-RHF Arm, LHF Wedge, Man Recl 48 x 42 x 42" 122 x 107 x 107cm IA: 23" / 58cm

9R-LHF Wedge, Man **8R-Armless Manual** Recliner 23 x 41 x 42" 40 x 42 x 42" 59 x 103 x 107cm 102 x 107 x 107cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty

Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41408 EQUALIZER

PALLISER®


Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.



2 SEATS STRAIGHT (1_/3_)

70 x 70" 178 x 177cm



4 SEATS STRAIGHT (1_/3_/3_/3_) 4 SEATS CURVED (5_/7_/7_/3_)

133 x 70" 337 x 177cm




3 SEAT STRAIGHT (2_/8_/3_)

86 x 70" 219 x 177cm




2 SEATS CURVED (5_/3_)

79 x 72" 200 x 184cm



154 x 82"

392 x 208cm



4 SEATS CURVED (5_/4_/6_)


141 x 76" 358 x 194cm



3 SEATS STRAIGHT (1_/3_/3_)

102 x 70"

258 x 177cm



4 SEATS STRAIGHT (1_/4_/1_)

125 x 70" 318 x 177cm



3 SEATS CURVED (5_/7_/3_)

118 x 75"

299 x 191cm



2 SEATS STRAIGHT (2_/3_)

63 x 70"

159 x 177cm