


How to Adjust and Level Your Shuffleboard Table

Having problems leveling your Shuffleboard Table? Pucks flying off the edge or going toward the middle? Here are some steps to fix the issues:

Convex Table Adjustment (Hump)



In this picture the table has a hump in the middle and pucks are falling off the side edge.

To adjust your table in this condition:


1. Loosen Nut B all the way on both sides.
2. Tighten Nut A SLOWLY - a couple of turns. Do the same to each side for uniform effect.
3. Repeat process a few times, as necessary, allowing time in between (Days) for change to fully take effect.

SEE NEX PAGE FOR CANCAVE TABLE

Pool Tables Plus

A Unique Collection of Style and Fun for The Home

Concave Table Adjustment (Dip)



In this picture the table has a dip in the middle and pucks are sliding toward the middle of the table. To adjust your table in this condition:

1. Loosen Nut A all the way on both sides.
2. Tighten Nut B SLOWLY - a couple of turns. Do the same to each side for uniform effect.
3. Repeat process a few times, as necessary, allowing time in between (Days) for change to fully take effect.



If you are still having issues? Please give us a call.